

```
From pathlib import Path
```

```
Window = tk.Tk()
Window.title("Face_Recogniser")
Window.configure(background ='white')
Window.grid_rowconfigure(0, weight = 1)
Window.grid_columnconfigure(0, weight = 1)
Message = tk.Label(
  Window, text = "Face-Recognition-System",
  Bg = "green", fg = "white", width = 50,
  Height = 3, font = ('times', 30, 'bold'))
Message.place(x = 200, y = 20)
```

Lbl = tk.Label(window, text = "No.",

Width = 20, height = 2, fg = "green",

Bg = "white", font = ('times', 15, 'bold '))

Lbl.place(x = 400, y = 200)

Txt = tk.Entry(window,

Width = 20, bg ="white",

Fg ="green", font = ('times', 15, 'bold '))

Txt.place(x = 700, y = 215)

Lbl2 = tk.Label(window, text ="Name",

Width = 20, fg = "green", bg = "white",

Height = 2, font =('times', 15, 'bold'))

Lbl2.place(x = 400, y = 300)

Txt2 = tk.Entry(window, width = 20,

Bg ="white", fg ="green",

```
Font = ('times', 15, 'bold ') )
Txt2.place(x = 700, y = 315)
# The function below is used for checking
# whether the text below is number or not?
Def is_number(s):
 Try:
    Float(s)
    Return True
  Except ValueError:
    Pass
 Try:
    Import unicodedata
    Unicodedata.numeric(s)
    Return True
```

```
Except (TypeError, ValueError):
    Pass
  Return False
# Take Images is a function used for creating
# the sample of the images which is used for
# training the model. It takes 60 Images of
# every new user.
Def TakeImages():
  # Both ID and Name is used for recognising the Image
  Id =(txt.get())
  Name =(txt2.get())
  # Checking if the ID is numeric and name is Alphabetical
  If(is_number(Id) and name.isalpha()):
    # Opening the primary camera if you want to access
```

```
# the secondary camera you can mention the number
# as 1 inside the parenthesis
Cam = cv2.VideoCapture(0)
# Specifying the path to haarcascade file
harcascadePath = "data\haarcascade_frontalface_default.xml"
# Creating the classier based on the haarcascade file.
Detector = cv2.CascadeClassifier(harcascadePath)
# Initializing the sample number (No. Of images) as 0
sampleNum = 0
while(True):
 # Reading the video captures by camera frame by frame
 Ret, img = cam.read()
 # Converting the image into grayscale as most of
 # the the processing is done in gray scale format
```

# It converts the images in different sizes

# (decreases by 1.3 times) and 5 specifies the

# number of times scaling happens

Faces = detector.detectMultiScale(gray, 1.3, 5)

# For creating a rectangle around the image

For (x, y, w, h) in faces:

# Specifying the coordinates of the image as well

# as color and thickness of the rectangle.

# incrementing sample number for each image

Cv2.rectangle(img, (x, y), (

$$X + w, y + h$$
, (255, 0, 0), 2)

sampleNum = sampleNum + 1

```
# saving the captured face in the dataset folder
  # Training I mage as the image needs to be trained
  # are saved in this folder
  Cv2.imwrite(
    "TrainingImage\"+name+"."+Id+'.'+str(
      sampleNum) + ".jpg", gray[y:y+ h, x:x + w])
  # display the frame that has been captured
  # and drawn rectangle around it.
  Cv2.imshow('frame', img)
# wait for 100 milliseconds
If cv2.waitKey(100) & 0xFF == ord('q'):
  Break
# break if the sample number is more than 60
Elif sampleNum>60:
```

```
# releasing the resources
Cam.release()
# closing all the windows
Cv2.destroyAllWindows()
# Displaying message for the user
Res = "Images Saved for ID: " + Id +" Name: "+ name
# Creating the entry for the user in a csv file
Row = [Id, name]
With open('UserDetails\UserDetails.csv', 'a+') as csvFile:
  Writer = csv.writer(csvFile)
  # Entry of the row in csv file
 Writer.writerow(row)
csvFile.close()
```

message.configure(text = res)

Break

```
else:
    if(is_number(Id)):
      res = "Enter Alphabetical Name"
      message.configure(text = res)
    if(name.isalpha()):
      res = "Enter Numeric Id"
      message.configure(text = res)
# Training the images saved in training image folder
Def TrainImages():
  # Local Binary Pattern Histogram is an Face Recognizer
  # algorithm inside OpenCV module used for training the image dataset
  Recognizer = cv2.face.LBPHFaceRecognizer_create()
  # Specifying the path for HaarCascade file
  harcascadePath = "data\haarcascade_frontalface_default.xml"
```

```
# creating detector for faces
  Detector = cv2.CascadeClassifier(harcascadePath)
  # Saving the detected faces in variables
  Faces, Id = getImagesAndLabels("TrainingImage")
  # Saving the trained faces and their respective ID's
  # in a model named as "trainner.yml".
  Recognizer.train(faces, np.array(Id))
  Recognizer.save (``TrainingImageLabel\Trainner.yml'')
  # Displaying the message
  Res = "Image Trained"
  Message.configure(text=res)
Def getImagesAndLabels(path):
  # get the path of all the files in the folder
  imagePaths =[os.path.join(path, f) for f in os.listdir(path)]
```

```
faces =[]
# creating empty ID list
Ids =[]
# now looping through all the image paths and loading the
# Ids and the images saved in the folder
For imagePath in imagePaths:
  # loading the image and converting it to gray scale
  pillmage = Image.open(imagePath).convert('L')
  # Now we are converting the PIL image into numpy array
  imageNp = np.array(pillmage, 'uint8')
  # getting the Id from the image
  Id = int(os.path.split(imagePath)[-1].split(".")[1])
  # extract the face from the training image sample
  Faces.append(imageNp)
```

```
Ids.append(Id)
  Return faces, Ids
# For testing phase
Def TrackImages():
  Recognizer = cv2.face.LBPHFaceRecognizer_create()
  # Reading the trained model
  Recognizer.read("TrainingImageLabel\Trainner.yml")
  harcascadePath = "data\haarcascade_frontalface_default.xml"
  faceCascade = cv2.CascadeClassifier(harcascadePath)
  # getting the name from "userdetails.csv"
  Df = pd.read_csv("UserDetails\UserDetails.csv")
  Cam = cv2.VideoCapture(0)
  Font = cv2.FONT_HERSHEY_SIMPLEX
  While True:
    Ret, im = cam.read()
```

```
Gray = cv2.cvtColor(im, cv2.COLOR_BGR2GRAY)
Faces = faceCascade.detectMultiScale(gray, 1.2, 5)
For(x, y, w, h) in faces:
 Cv2.rectangle(im, (x, y), (x + w, y + h), (225, 0, 0), 2)
 Id, conf = recognizer.predict(gray[y:y+h, x:x + w])
 If(conf < 50):
    Aa = df.loc[df['Id'] == Id]['Name'].values
    Tt = str(Id) + "-" + aa
  Else:
    Id ='Unknown'
    Tt = str(Id)
  If(conf > 75):
    noOfFile = len(os.listdir("ImagesUnknown"))+1
    cv2.imwrite("ImagesUnknown\Image"+
    str(noOfFile) + ".jpg", im[y:y + h, x:x + w])
```

```
cv2.putText(im, str(tt), (x, y + h),
      font, 1, (255, 255, 255), 2)
    cv2.imshow('im', im)
    if (cv2.waitKey(1)== ord('q')):
      break
  cam.release()
  cv2.destroyAllWindows()
takeImg = tk.Button(window, text = "Sample",
command = TakeImages, fg ="white", bg ="green",
width = 20, height = 3, activebackground = "Red",
font =('times', 15, 'bold '))
takeImg.place(x = 200, y = 500)
```

```
trainImg = tk.Button(window, text = "Training",
command = TrainImages, fg ="white", bg ="green",
width = 20, height = 3, activebackground = "Red",
font =('times', 15, 'bold '))
trainImg.place(x = 500, y = 500)
trackImg = tk. Button(window, text ="Testing",
command = TrackImages, fg ="white", bg ="green",
width = 20, height = 3, activebackground = "Red",
font =('times', 15, 'bold '))
trackImg.place(x = 800, y = 500)
quitWindow = tk.Button(window, text ="Quit",
command = window.destroy, fg ="white", bg ="green",
width = 20, height = 3, activebackground = "Red",
font =('times', 15, 'bold '))
quitWindow.place(x = 1100, y = 500)
```

window.mainloop()